

ESBB01 Easy Step Bottom Brace Kit



ES-0024	Bottom Brace Bracket
ES-0026	Bottom Knee Brace
Fastener Package	8 qty ea. 5/16-18x.75 FLCS and 5/16-18 WHZNUT
Instruction Sheet	

1. Attach ES-0026 Bottom Knee Brace to the rear inside hole of the bottom step
2. Attach the other end of the ES-0026 to the ES-0002 Wall Cross in the hole that would normally have a knee brace as pictured above.

NOTE: On some bin diameters this may not work. If the stair system has to be severely deformed to use this hole, simply drill a hole to allow connection.

3. Attach the ES-0024 Bottom Brace Bracket to the inside and outside siderails under the bottom step so as to not be in the walk path when coming off of the step.
4. On Bins with a rolled flange bottom ring it may be necessary to move the bottom brace up to the step bolts for the upper holes.
5. If possible, attach the bottom post to the bottom brace bracket. If that causes the post to be misaligned with the handrail and intermediate rail, then attaching them separately to the outside siderail will be adequate.