





AMA03008 Assembly and Dimensions









IN-AMA03008, 1/19/23




AMA03008 Parts List

PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	AM-06096	Z Rail, 6" x 2" x 96"
2	2	AM-20001	End Cross Support
3	2	AM-20002	Post Cross Support
4	1	AM-20003	Mid Cross Support
5	4	AM-30001	Left Post
6	4	AM-30002	Right Post
7	2	AM-40001	Kickboard, 48"
8	4	AM-40002	Kickboard, 24"
9	2	AM-62430	Deck Tread, 24" x 30"
10	1	AM-64830	Deck Tread, 48" x 30"
11	2	TR1009600	96 in 1.00 Tubing No Swage
12	2	TR1509600	96 in 1.50 Tubing No Swage










Position Z rails as shown and attach the mid cross supports and post cross supports. The posts may be added at the post cross supports.


Leave connections loose until structure is assembled.





Install the 24" deck treads on the ends, and the 48" deck tread in the center section. The raised tread pattern faces up to provide the walking surface.





Handrail Clamp Installation Instructions

- Position the handrail clamp so it is oriented facing outward, and so it does not interfere into the width of the stairs or walkway.
- Insert the bolt through both holes on the handrail clamp first, then push the bolt through the hole in the post from the inside. Install the nut on the outside so that the bolt head is on the inside of the stairs.
- Fasten the clamp tightly together so it is closed around the handrail, making sure the post is not between the two tabs.
- Install a self-drilling screw into the handrail clamp and through the handrail. It should be positioned on the outside near the bottom, approximately as shown, to minimize contact with the hands.

