




MASTER ASSEMBLY


PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	AMA03012	12ft intermediate manwalk section
2	1	AMB03012	12ft base manwalk section
3	1	ASeries manwalk 2 section truss	24ft truss kit







Truss Assembly and AM-80002 parts breakdown






	PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION	
1	4	AM-06144	Z-Rail,6"x2"x144"	
2	5	AM-64830	Deck Tread, 48"X30"	
3	2	AM-62430	Deck Tread, 24" x 30"	
4	6	AM-20002	Post Cross Support	
5	2	AM-20001	End Cross Support	
6	8	AM-30001	Left Post	
7	8	AM-30002	Right Post	
8	4	AM-20003	Mid Cross Support	
9	4	AM-40002	24" kickboard	
10	10	AM-40001	48" kickboard	
11	16	HRC1500	Handrail Clamp for 1.5 in	
12	20	floor screw	Self tapping screw	
13	2	TR1515006	1.50 in 1 in dia tubing 6in swage	
14	2	TR1015006	1.00 in 1 in dia tubing 6in swage	
15	1	AM-20004	Splice Cross Support	
16	4	AM-50001	Z Rail Splice Plate	
17	2	AM-50002	Truss Plate 24" x 24", 8" hole	
18	4	AM-50004	Truss Plate X Brace	
19	2	AM-50003	Truss Plate Cross Brace	
20	4	AM-80002	Diagonal Truss Tie 12'	






STEP 3 : Splicing the 12ft Sections

PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION
17	2	AM-50002	Truss Plate 24" x 24", 8" hole
20	4	AM-80002	Diagonal Truss Tie 12'
21	2	TR1014400	144 in 1.5 in dia tubing no swage
22	2	TR1514400	144 in 1.5 in dia tubing no swage




STEP 4 : Adding the Truss plates and Diagonal Truss ties


PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION
17	2	AM-50002	Truss Plate 24" x 24", 8" hole
20	4	AM-80002	Diagonal Truss Tie 12'
21	2	TR1014400	144 in 1.5 in dia tubing no swage
22	2	TR1514400	144 in 1.5 in dia tubing no swage



STEP 5 : Assembling the Truss Assembly

PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION
18	4	AM-50004	Truss Plate X Brace
19	2	AM-50003	Truss Plate Cross Brace
21	2	TR1014400	144 in 1.5 in dia tubing no
			swage
22	2	TR1514400	144 in 1.5 in dia tubing no
			swage







STEP 7 : Adding the Decks

PARTS LIST			
ITEM	QTY	PART NUMBER	DESCRIPTION
2	5	AM-64830	Deck Tread, 48"X30"
3	2	AM-62430	Deck Tread, 24" x 30"
21	2	TR1014400	144 in 1.5 in dia tubing no
			swage
22	2	TR1514400	144 in 1.5 in dia tubing no
			swage

Now go ahead and throw on the larger Deck Tread, 48in and the smaller Deck Tread,24in



STEP 8 : Adding the Kickboards



Handrail Clamp Installation Instructions

- Position the handrail clamp so it is oriented facing outward, and so it does not interfere into the width of the stairs or walkway.
- Insert the bolt through both holes on the handrail clamp first, then push the bolt through the hole in the stair post from the inside. Install the nut on the outside so that the bolt head is on the inside of the stairs.
- Fasten the clamp tightly together so it is closed around the handrail, making sure the post is not between the two tabs.
- Install a self-drilling screw into the handrail clamp and through the handrail. It should be positioned on the outside near the bottom, approximately as shown, to minimize contact with the hands.

