# AVT44071 AVT44081 AVT44091

4x4 Platform with Variable 6 ft Elevation







#### PARTS LIST PART NUMBER **ITEM DESCRIPTION** QTY **4x4 Platform Components** Bracket, Foot AVT-1003 1 4 (Packed together on skid) Angle, Post, 60" 2 4 AVT-1060 3 Angle, Cross Brace 60" 6 AVT-1065 Angle, Cross Brace 64" 4 2 AVT-1064 5 4 AVT-4002 Angle, Post, Top Long Channel, Siderail, Platform 4 AVT-4003 6 7 AVT-4004 Channel, Support Crossmember 1 8 2 AVT-4015 Landing Platform Brace 9 2 Landing Tread Plate AVT-4005 10 1 ART-1015 Right Stair Post, Guardrail Left Stair Post, Guardrail ART-1016 11 1 Bracket, Stair Mount Top 12 2 AVT-5001 13 2 AVT-4012 Channel, Kickboard, Entry 14 2 AVT-4013 Strap, Mid Rail, Entry Channel, Kickboard 15 3 AVT-4006 Strap, Mid Rail, 4' 16 3 AVT-4014 Walkaround Top Rail 17 3 TRS1504700 18 2 ART-2226 **Bottom Handrail Loop** 14 10 16 11 15 18 12 6 13 2

## **Frame Assembly**

Bolt together the frame as shown Attach the braces to the deck tread and secure the treads to the frame






#### **Gaurding Components**


Select one side to be the entry point and install kickboards, intermediate rails, and handrails on the remaining three sides.

All components should be fastened to the inside surfaces of the posts.




## **Entry Components**


Attach the entry posts as shown. Secure the posts with the short kickboards and short midrails.



#### **Variable Height Landing Legs**

The AVT-1060 legs are designed to accommodate a range of platform heights, placing the deck surface between 66" and 80" above grade. Reference the table below for compatible stair configurations.








#### **Bracing Components**


On the stair entry side, use the AVT-1064 "X" braces. On the remaining sides, use the AVT-1065 "V" braces as shown.

Attach the AVT-1003 3x3 feet, use the anchor holes if needed to secure the structure to the ground.










Detail of "V" brace at platform mount location



Detail of "X" brace; opposed flanges

#### **Attach Stair Sections**

Assemble the A-series Variable stair sections from stair instruction documents. Attach upper end of frame to platform entry section as shown.

